

GOTOH

Bass Machine Heads



Printable actual size bass tuning machines

When printing the PDF, ensure that the page scaling is set to "none", "default", or "actual size." Use the 1-inch square to verify the accuracy of the printed PDF. You can cut out the images to check the size, placement of mounting holes, and dimensions of post hole.

The size of the post holes, marked in red, indicates the minimum required hole diameter. Press-in bushings should be size shown or slightly smaller. Threaded bushing should be about .5mm larger than shown.



FB30

1"



Press in bushing
Diameter 17.6mm (11/16")


GB2




Pressing in bushing
Diameter 17.6mm (11/16")

GB10

1"





GB11W





1"

GB350 GB707



Threaded bushing
Diameter 14mm (9/16")


GB528



Threaded bushing
Diameter 16mm (5/8")

1"

GB640 GBR640




Press in bushing
Diameter 17.6mm (11/16")

GRL510M-9

GBU 510M-9


1"



Threaded bushing
Diameter 14mm (9/16")

GRL510M-12

GBU 510M-12



Threaded bushing
Diameter 17mm (11/16")